

Oregon
Xplore

Gecko HD Camera
Model: ATC Gecko
Quick Start Guide

INFORMATION

POWER OFF: Press and hold the power/mode button (③) until there is a beep with quick 7 beeps.

SWITCH MODE: Toggle the power/mode button (③) to select your desired mode, the loop sequence is mode A, B and C. There is a beep when you press the button.

The corresponding indicator color is as follows while switching mode:

Mode	Indicator Color
Mode A	REC and ② are both in orange
Mode B	Only REC indicator is in orange
Mode C	Only ② indicator is in orange

START/STOP SHOTING: Once you select a mode, press the shutter button to start shooting, you will hear 2 beeps at the beginning of recording, and 4 beeps when recording ends.

WATERPROOF (IPX7): The camera is water-resistant up to 1 meter for half an hour. This means you can use the camera for simple water sport activity but it must not be used for snorkeling and deep water diving.

RESET: Press the power/mode button (③) and the shutter button at the same time to force the camera to shut down.

SPECIFICATIONS

Type	Description
Dimension	31.3 x 55.8 x 23.9 mm (1.2 x 2.2 x 0.9 inches)
USB port	Micro-USB port
Battery / memory level LED indicator	REC: Record status indicator
Lens	7mm
Top cover	Top cover
Metal connector	9mm
Stop gate	10mm

CHARGING: Charge the camera for at least 3 hours before your first use.

1. Plug small end of your provided USB cable into micro USB port of the camera.
2. Plug big end of the cable into USB port of your PC.
3. Red battery level indicator (REC) represents charging status. If battery is fully charged, no indicator is on.

MEMORY:

You need to insert a memory card before use. 8GB or above Micro SD card (Class 6 or above) is recommended for maximizing the camera's performance.

Capacity of Micro SD Card	Estimated Recording Time
1GB under 720p@30fps	8 minutes
1GB under VGA@60fps	11 minutes

INDICATORS:

For battery / memory level indicator (②), different colors represent the following meanings:

Indicator (②)	Status
Alternately flashes in red and orange	Battery level is below 20% capacity. Memory is less than 10 minutes video recording time / Memory less than 250MB for photo and time lapse.
Flashes in red	Battery level is below 20% capacity.
Flashes in orange	Memory is less than 10 minutes recording time / No memory card.
Green is on	Battery capacity above 20% / Memory capacity above 10 minutes recording time.
No indicator is on	Charging completed / Power off

GET STARTED

INSTALLATION:

Install your camera onto the clip mount or wrist mount. Align the metal connector with the clip or wrist mount, and then slide them into each other. The clip mount can be rotated 360 degrees for your convenience.

The wrist mount can be adjusted to your desired angle (0-180 degrees) and worn on your wrist by velcro strap.

DEFAULT SETTINGS:

Three shooting modes (video recording, photo shooting and time lapse) exist in your camera and have been set by factory default before shipment. REC indicator turns on when recording video.

Mode	Description
Mode A	Video recording-720p@30fps
Mode B	Photo - 1 photo taken each time
Mode C	Time lapse-3 seconds intervals

APPLICATION:

You need to download and install the "Gecko HD" software to set the details of your camera. Download the software through the below site:
<http://xplore.oregonscientific.com/GeckoHD/support.htm>

CONNECT THE CAMERA TO YOUR PC:

Use the Micro USB cable to connect the camera and your PC.

OPERATION:

Power on: Press and hold the power/mode button (③) until there is a beep and the REC indicators turn orange at the same time. The battery/memory level indicator is on.

INFORMATION

OVERVIEW

Power off:
Press and hold the power/mode button (③) until there is a beep with quick 7 beeps.

Switch mode:
Toggle the power/mode button (③) to select your desired mode, the loop sequence is mode A, B and C. There is a beep when you press the button.

The corresponding indicator color is as follows while switching mode:

Mode	Indicator Color
Mode A	REC and ② are both in orange
Mode B	Only REC indicator is in orange
Mode C	Only ② indicator is in orange

Start/stop shooting: Once you select a mode, press the shutter button to start shooting, you will hear 2 beeps at the beginning of recording, and 4 beeps when recording ends.

WATERPROOF (IPX7): The camera is water-resistant up to 1 meter for half an hour. This means you can use the camera for simple water sport activity but it must not be used for snorkeling and deep water diving.

Reset: Press the power/mode button (③) and the shutter button at the same time to force the camera to shut down.

FCC COMPLIANCE STATEMENT:

Press the power/mode button (③) and the shutter button at the same time to force the camera to shut down.

SPECIFICATIONS:

Type	Description
Dimension	31.3 x 55.8 x 23.9 mm (1.2 x 2.2 x 0.9 inches)
USB port	Micro-USB port
Battery / memory level LED indicator	REC: Record status indicator
Lens	7mm
Top cover	Top cover
Metal connector	9mm
Stop gate	10mm

PRECAUTIONS:

To ensure you use your product correctly and safely, read these warnings and the entire user manual before using the device.

• Use a soft, slightly moistened cloth. Do not use abrasive or corrosive cleaning agents, as these may cause damage. Use lukewarm water and mild soap if cleaning is required.

• Do not drop the product or expose it to water.

• Do not expose the product to excessive force, shock, dust, temperature changes, or humidity. Never expose the product to direct sunlight for extended periods.

• Such treatment may result in malfunction.

• Do not tamper with the internal components. Doing so will void the manufacturer's warranty and may cause damage. The camera contains no serviceable parts.

• The product is a precision instrument. Never attempt to repair this device yourself. Contact the retailer or our customer service department if the product requires service.

• Check all major functions if the device has not been used for a long time. Maintain regular internal testing and cleaning of your device to prevent damage.

• When stopping of this product, ensure it is collected separately for special treatment and not as normal household waste.

• Due to physical limitations, the displays shown in this manual may differ from the actual display.

• The contents of this manual may not be reproduced without the permission of the manufacturer.

NOTE:

The technical specifications for this product and the contents of the user manual are subject to change without notice.

NOTE:

Features and accessories will not be available in all countries. For more information, please contact your local retailer.

DISCLAIMER:

"Oregon Scientific" shall mean Oregon Scientific Global Distribution Limited, its subsidiaries, parent companies, affiliated companies, directors, officers, employees, agents, representatives and distributors. Oregon Scientific do not warrant against loss of any data stored on the unit or on the product, and makes no liability for such losses. Purchaser assumes all responsibility and such as which releases us from any liability, for accident, injury, damage, death, illegal activity or any other claim that may occur resulting from or during use of the Product or otherwise, nor such as foreseeable by Oregon Scientific.

ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED TO THE DURATION OF THE EXPRESS WARRANTY. ALL OTHER EXPRESS OR IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF NON-INFRINGEMENT, ARE DISCLAIMED TO THE MAXIMUM EXTENT ALLOWED BY THE APPLICABLE JURISDICTION.

All third party software provided with the Product is licensed "AS IS". Purchaser assumes all risk as to the quality, performance, accuracy and effect of such software and hardware it provides. Oregon Scientific, and not Oregon Scientific, assumes the entire cost of all necessary servicing or repair.

TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL OREGON SCIENTIFIC BE LIABLE FOR ANY LOSS, DATA, REVENUE OR PROFIT, OR FOR SPECIAL, INDIRECT, INCIDENTAL, CONSEQUENTIAL OR PUNITIVE DAMAGES, HOWEVER CAUSED, REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF OR RELATED TO THE USE OF THE PRODUCT, WHETHER IN CONTRACT, TORT, OR OTHERWISE. IF WE HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, IN NO EVENT WILL OREGON SCIENTIFIC LIABILITY EXCEED THE AMOUNT PAID BY PURCHASER FOR THE PRODUCT.

All applicable laws and regulations require that Oregon Scientific do not promote or endorse use of the Product or its services. Oregon Scientific is not responsible for personal injuries or property damage incurred during such use.

Oregon Scientific is not liable for use or misuse of the Product or any video captured that may be considered illegal.

Oregon Scientific is not responsible for any illegal actions taken while recording, attempting to record, or editing video that was captured with the Product.

The Product's primary purpose is for recording legal sports activities as seen by all applicable laws and regulations.

Connect the camera to your PC:

Use the Micro USB cable to connect the camera and your PC.

OPERATION:

Power on: Press and hold the power/mode button (③) until there is a beep and the REC indicators turn orange at the same time. The battery/memory level indicator is on.

INFORMATION

FUNCTIONAMENTO

Acescione:

Tener premuto el pulsante accensione / modalità (③) fino a sentir un segnale acustico e finché i due indicatori LED sono illuminati en orange en la parte delantera del dispositivo.

Oregon Scientific no promove o aprova uso del producto en electrico y electronicos como es el caso de los dispositivos de comunicacion.

Spogamento:

Tener premuto el tasto accensione/modalità fino a que no se intone sonido alguno.

Cambiamento de las modalidades:

Pulsare il pulsante accensione / modalità (③) per selezionare la modalità desiderata.

Le Zylinderfolie ist Modus A und C. Wenn Sie die Taste drücken, erfolgt ein Signalton.

Oregon Scientific no es responsable de alcuna accion ilegal durante el uso del dispositivo.

Algunas leyes prohíben el uso de dispositivos de comunicacion.

modo:

Tener premuto el tasto accensione/modalità (③) para seleccionar el modo deseado.

Los colores de los indicadores corresponden a los diferentes modos son los siguientes :

Modo	Indicador Color
Modo A	REC y ② son ambos en orange
Modo B	Solo el indicador REC es en orange
Modo C	Solo el indicador ② es en orange

Start/stop shooting:

Una vez seleccionado un modo, presione el botón de disparo para comenzar la grabación, escuchará 2 pitidos al principio de la grabación, y 4 pitidos cuando finalice la grabación.

WATERPROOF (IPX7):

La cámara es resistente al agua hasta 1 metro por media hora. Esto significa que puede usar la cámara para actividades deportivas sencillas, pero no para buceo ni nadar.

RESET:

Presione el botón de encendido (③) y el botón de disparo al mismo tiempo para reiniciar la cámara.

FCC COMPLIANCE STATEMENT:

Presione el botón de encendido (③) y el botón de disparo al mismo tiempo para reiniciar la cámara.

INFORMACIONES:

INFORMACIÓN:

OPERACIÓN:

POWER OFF: Presione y mantenga el botón de encendido (③) hasta que escuche 7 pitidos rápidos.

SWITCH MODE: Toque el botón de encendido (③) para seleccionar su modo deseado, el orden de los modos es modo A, B y C. Hay un pitido cada vez que pulse el botón.

RECHARGE: Mantenga presionado el botón de encendido (③) y el botón de disparo al mismo tiempo para reiniciar la cámara.

INFORMATION:

INFORMACIÓN:

OPERACIÓN:

POWER OFF: Presione y mantenga el botón de encendido (③) hasta que escuche 7 pitidos rápidos.

SWITCH MODE: Toque el botón de encendido (③) para seleccionar su modo deseado, el orden de los modos es modo A, B y C. Hay un pitido cada vez que pulse el botón.

CHARGE: Mantenga presionado el botón de encendido (③) y el botón de disparo al mismo tiempo para reiniciar la cámara.

INFORMATION:

INFORMACIÓN:

OPERACIÓN:

POWER OFF: Presione y mantenga el botón de encendido (③) hasta que escuche 7 pitidos rápidos.

SWITCH MODE: Toque el botón de encendido (③) para seleccionar su modo deseado, el orden de los modos es modo A, B y C. Hay un pitido cada vez que pulse el botón.

CHARGE: Mantenga presionado el botón de encendido (③) y el botón de disparo al mismo tiempo para reiniciar la cámara.

INFORMATION:

INFORMACIÓN:

OPERACIÓN:

POWER OFF: Presione y mantenga el botón de encendido (③) hasta que escuche 7 pitidos rápidos.

SWITCH MODE: Toque el botón de encendido (③) para seleccionar su modo deseado, el orden de los modos es modo A, B y C. Hay un pitido cada vez que pulse el botón.

CHARGE: Mantenga presionado el botón de encendido (③) y el botón de disparo al mismo tiempo para reiniciar la cámara.

INFORMATION:

INFORMACIÓN:

OPERACIÓN:

POWER OFF: Presione y mantenga el botón de encendido (③) hasta que escuche 7 pitidos rápidos.

SWITCH MODE: Toque el botón de encendido (③) para seleccionar su modo deseado, el orden de los modos es modo A, B y C. Hay un pitido cada vez que pulse el botón.

